


X-CT Nails for Forming or other Temporary uses

Product data

Dimensions



General information

Material specifications

Carbon steel shank: HRC 53
Zinc coating: 5–13 µm

Fastening tools

DX 460-F8, DX 460 MX, DX 36, DX E-72

See fastener selection for more details.

Applications

Examples



Conventional Formwork


8/2011



System Formwork



To position and hold concrete formwork



Fasten plastic, netting, etc.

2.97



Load data

Design data

Recommended loads




 $V_{rec} = 0.3 \text{ kN for h}_{ET} \ge 22 \text{ mm}$

Conditions:

- Static loading only (placing and vibration of concrete does not affect design).
- Minimum 5 fastenings per fastened unit.

Application requirements

Thickness of base material



Concrete

 $h_{min} = 80 \text{ mm}$

Thickness of fastened material

 $t_1 = 20-50 \text{ mm}$

Edge distances [mm]



c ≥ 70 mm

Fastener selection and system recommendation

Fastener selection


Required nail shank length:

$$L_S = h_{ET} + t_I [mm]$$

Recommendation:

Concrete

 $h_{ET} = 22 \text{ mm}$





Fastener selection and system recommendation


Fasteners						OIS	•		
					×	82			
	Item no.		l.	l .	460	460	36	E72	
Designation	Packs of 1000 nails	100 nails	Ls [mm]	d _{nom} [mm]	X	Ϋ́	ă	×	Key applications
		Too Halls			_	_	_	_	, , ,
X-CT 47 MX	383588		47	3.7					Wood to concrete
X-CT 52 MX	383589	383576	52	3.7					Wood to concrete
X-CT 62 MX	383591	383579	62	3.7					Wood to concrete
X-CT 72 MX		383580	62	3.7					Wood to concrete
X-CT 47 DP8		383582	47	3.7					Wood to concrete
X-CT 52 DP8		383583	52	3.7					Wood to concrete
X-CT 62 DP8		383585	62	3.7					Wood to concrete
X-CT 72 DP8		383586	72	3.7					Wood to concrete
X-CT 97 DP8		383587	97	3.7					Wood to concrete

MX: collated nails for magazine recommended


Cartridge recommendation:

Green concrete: 6.8/11M green
Normal concrete: 6.8/11M yellow


Removal instruction




1. Fastening using proper nail length



2. Pry wood off over head of nail



3. Use piece of steel pipe with inner diameter of 10 mm) to break off nail



4. Nail is broken off at grade with minimum concrete damage.

8/2011 2.99



2.100 8/2011